


INSTALLATION - SERVICE INSTRUCTIONS



765 South Pierce Avenue, Louisville, CO 80027
(303) 665-6901 / 800-525-1963

SERVICE BULLETIN

NO. 0041 PAGE 1 OF 1

QUICK RELEASE HUBS

JANUARY 24, 1995

PART NUMBER : **DESCRIPTION :**

ALL MW QUICK RELEASE HUBS MEETS S.F.I. SPEC 42.1.

10020	QUICK RELEASE HUB FOR DRAGSTER/FUNNY CAR
10025	QUICK RELEASE HUB FOR 5 HOLE GRANT STEERING WHEEL (3/16" HOLES, 5 X 2.86 BOLT CIRCLE)
10060	QUICK RELEASE HUB FOR 3 HOLE DON LONG STEERING WHEEL (10-32 THREADS)
10070	QUICK RELEASE HUB FOR 3 HOLE OVAL TRACK (1/4" THREADS ON 1.75 BOLT CIRCLE)
10075	QUICK RELEASE HUB FOR 3 HOLE OVAL TRACK (5/16" THREADS ON A 1.75 BOLT CIRCLE)
10080	QUICK RELEASE HUB, UNIVERSAL (NO HOLES)

PART INCLUDED :

1-HUB , 1-SPLINED SLEEVE, 1-RELEASE SLEEVE, 3- BALL BEARINGS, 1 SPRING, AND MOUNTING HARDWARE.

PRIMARY APPLICATION :

ANY.

INSTALLATION OVERVIEW :

- 1) TURN WHEELS STRAIGHT, REMOVE OLD WHEEL.
- 2) PLACE SPLINED STEERING SHAFT WITH 1-TOOTH OMITTED ON STEERING COLUMN. LOCATE 1-TOOTH OMITTED SERRATION AND PLACE AT 12:00 O'CLOCK FOR EASY STEERING INDEXING.
- 3) BOLT OR WELD SPLINED SHAFT TO STEERING COLUMN.
- 4) BOLT STEERING WHEEL TO QUICK RELEASE HUB.

